

8000 Foothills Blvd., Roseville, CA 95678 Telephone 916-786-8000

John, Dan, and Bill:

When we discussed SAD READ underlengths at the last plenary (very briefly!) I'm not sure we understood how dynamic our system constraints were on buffer allocation. As it turns out, HP systems DO dynamically allocate buffer space on variable-length reads, and would therefore be required to issue a MODE SELECT on every variable-length READ command.

George Penokie's proposal (89-21) precisely addressed this problem, but George deferred to a different solution from Dan. Since then, Pete Bramhall from HP Bristol has discussed this with Gary and George from IBM, and indicated to me that we might have some agreement to reconsider George's initial proposal (using one of the three Reserved bits in the READ CDB as "SULI"). Apparently, George's folks back at Rochester are not necessarily convinced that the subsequent alternatives to 89-21 meet their needs, either.

I wanted to ask you to take another look at 89-21, and reconsider its inclusion into Rev 8, if procedure allows for changes at this late date. Please feel free to contact me or Pete if you have any questions.

Thanks,

Kurt Chan Pete Bramhall 916-785-5621 0272-799910

PS (If you call Bristol, do it early - Pete is 8 hours ahead of California!)

cc: George Penokie Gary Stevens

X3T9.2/89-21

Date:01/17/89

To: X3T9 committee

From: George Penokie/Jason Clegg, IBM Corporation Subject: SCSI-2 Architecture change, tape read underlength

Proposed change to the READ and READ REVERSE commands for Sequential Access Devices (ref section 9.2.5 & 9.2.8, SCSI-2, draft rev 6a).

Problem Description:

For many applications, underlengths (i.e. actual block length less than the transfer length) can occur frequently. Since this operation can be 'typical', it should proceed with good performance. This can be accomplished by eliminating the Check Condition after the READ (the actual number of bytes transfered can be determined from the initiators transfer counter). The SILI bit, however, can not be used to accomplish this, because the SILI bit suppresses overlengths (actual block length greater than the transfer length). Overlengths must be detected and reported to the application. (SILI bit effectively 'ignores' overlengths - they are NOT detected). In addition, the initiator may not have space for a buffer of the largest possible block size on the target, and the initiator may not want to consume more SCSI bus time if the data block on the target is longer than expected. Hence, the need to cap transfer length, allow good performance on underlength situations (by eliminating the Check -Gondition AND detect overlengths.

Proposed Solution:

Define a new bit in the READ command in CBD byte 1, bit 2. This bit shall be called 'SULI' - Suppress UnderLength Indication.

The SULI bit is mutually exclusive with the SILI bit (i.e., only one bit shall be on). If the SULI bit is one, the target shall not return CHECK CONDITION status if the only error is that the actual block length is less than the transfer length.

(If the actual block length is greater than the transfer length, with no other errors, the target shall return CHECK CONDITION status and the ILI and valid bits shall be set to one in the sense data). The SULI bit option is only valid when the FIXED bit is zero.