

To: T10 Technical Committee
 From: Tim Symons, PMC-Sierra (Tim_Symons@pmc-sierra.com)
 Date: 28 August 2006
 Subject: 06-289r6 SAS-2 SMP ZONE UNLOCK

Revision Information

- Revision 0: First draft.
- Revision 1: Renamed function. Added request codes and moved lock definitions into proposal 06-286.
- Revision 2: Text edits – update CRC section references, function result priority listing.
- Revision 3: Moved activate Broadcast to this function. Removed time-out references as these belong in the time-out proposal 06-326.
- Revision 4: Renamed the function to SMP ZONE UNLOCK.
- Revision 5: Added EXPECTED EXPANDER CHANGE COUNT field. Revised Broadcast (Change) origination rules to use the SMP ZONED BROADCAST function.
- **Revision 6: Changes per Seattle working group meeting**

Referenced Document

sas2r05a Serial Attached SCSI – 2 (SAS-2) revision 5a
 06-201r6 SAS-2 SMP Configure phy zone (Tim Symons, PMC-Sierra)
 06-286r5 SAS-2 SMP ZONE LOCK (Tim Symons, PMC-Sierra).
 06-288r6 SAS-2 SMP ZONE ACTIVATE function (Tim Symons, PMC-Sierra)
 06-358r3 SAS-2 Zone Configuration model (Tim Symons, PMC-Sierra)
 06-326r1 SAS-2 SMP Zone Lock Timer (Tim Symons, PMC-Sierra)

Overview

The active zone manager uses SMP ZONE UNLOCK to unlock zoning expander devices **by setting the ZONE LOCKED bit to zero. When a zoning expander device has the ZONE LOCKED bit set to zero, it may be locked by a zone manager.**

 [Suggested addition to SAS-2 existing text (included in black), new additional text (included in blue) and changes between revisions shown in red]

10.4.3.1 SMP function request frame format

Table 196 – SMP functions (FUNCTION field)

Code	SMP function	Description	Reference
88h	ZONE UNLOCK	Unlocks a zoning expander device	10.4.3.xx
...			

 Editors Note: Suggestion: 85h-8Fh could be assigned to zoning functions:
 85h: ZONE BROADCAST (already defined)
 86h: SMP ZONE LOCK
 87h: SMP ZONE ACTIVATE
 88h: SMP ZONE UNLOCK
 89h: Reserved for zoning SMP functions
 8Ah: CONFIGURE PHY ZONE
 8Bh: CONFIGURE ZONE PERMISSION
 8Ch – 8Fh: Reserved for zoning SMP functions

10.4.3.2 SMP function response frame format

Table 201 – FUNCTION RESULT field

Code	Name	SMP function(s)	Description
xxh	BUSY	ZONE UNLOCK	A zoning expander device receives a ZONE UNLOCK request and has received but not completed an activate step.
21h	ZONE LOCK VIOLATION	ZONE UNLOCK	A zoning expander device that is zone locked, receives an SMP zone locked request function from a source that is not the active zone management client, or when the zoning expander device is not locked.
xxh	NOT ACTIVATED	ZONE UNLOCK	A zoning expander device receives a ZONE UNLOCK request with the ACTIVATE REQUIRED bit set to one, and has not received an activate step.

...

Table xx - Function result priority per SMP Function

SMP Function (per table 197)	SMP Function Result Priority
ZONE UNLOCK	1) INVALID REQUEST FRAME LENGTH 2) ZONE LOCK VIOLATION 3) NOT ACTIVATED 4) BUSY 5) SMP FUNCTION FAILED 6) SMP FUNCTION ACCEPTED

...

10.4.3.xx ZONE UNLOCK function

All zoning expander devices shall support this function.

If a locked zoning expander device receives a ZONE UNLOCK request from the active zone manager then the ZONE LOCKED bit shall be set to zero. If the CONFIGURING bit has been set to one then either of the following shall be sent:

- a) for each port that has zone group access permission to zone group 3, the zoning expander device shall originate a ZONED BROADCAST (see 10.4.3.16) with type Broadcast (change) for each zone group that changed; or
- b) for each port that does not have zone group access permission to zone group 3, the zoning expander device shall originate a Broadcast (Change).

If a zoning expander device receives a ZONE UNLOCK request that not originated by the active zone manager or when the zoning expander device is not locked then the response FUNCTION RESULT field should be ZONE LOCK VIOLATION

Table 1 defines the ZONE UNLOCK request format.

Table 1 – ZONE UNLOCK request

Byte\Bit	7	6	5	4	3	2	1	0	
0	SMP FRAME TYPE (40h)								
1	FUNCTION (88h)								
2	Reserved								
3	REQUEST LENGTH (01h)								
4	Reserved								
5	Reserved								
6	Reserved							ACTIVATE REQUIRED	
7	Reserved								
8	(MSB)	CRC							
11								(LSB)	

The SMP FRAME TYPE field shall be set to 40h.

The FUNCTION field shall be set to 88h.

The REQUEST LENGTH field shall be set to (00h).

The EXPECTED EXPANDER CHANGE COUNT field is defined in 10.4.3.3

An ACTIVATE REQUIRED bit set to one specifies that the zoning expander device shall be unlocked only if the activate step has been completed. An ACTIVATE REQUIRED bit set to zero specifies that the zoning expander device shall be unlocked.

The CRC field is defined in 10.4.3.1.

The ZONE UNLOCK response format is defined in Table 2.

Table 2 – ZONE UNLOCK response

Byte\Bit	7	6	5	4	3	2	1	0	
0	SMP FRAME TYPE (41h)								
1	FUNCTION (88h)								
2	FUNCTION RESULT								
3	RESPONSE LENGTH (00h)								
4	(MSB)	CRC							
7								(LSB)	

The SMP FRAME TYPE field shall be set to 41h.

The FUNCTION field shall be set to 88h.

The FUNCTION RESULT field is defined in 10.4.3.2

T10/06-289r6 SAS-2 SMP ZONE UNLOCK

The RESPONSE LENGTH field shall be set to 00h.

The CRC field is defined in 10.4.3.2.