

TO : John Lohmeyer, Chairman, X3T9.2 Committee (SCSI)
: Membership, X3T9.2 Committee (SCSI)
FROM : Doug Pickford, Western Digital Corporation
Subject : Proposed Extensions for SCSI-3, Standard Physical Layer Access
Date : September 1, 1990
Document : X3T9.2/89-103, Rev 1
File : ANSIDGS3.WRI/ANSIDG3A.WRI

Enclosed herein is a first cut of a Diagnostic Model for the DCS command extensions along with the second pass of the command set itself.

8.14 Direct Access Devices, Physical Layer Model

Despite the thoroughness of the Logical level interface provided by SCSI, it remains a fact to be dealt with that Direct Access Devices (Rotating Media) are comprised of mechanical components and Analog and Digital Circuitry with pre-established design tolerances. While the SCSI target typically presents consistent data to the initiator, the target may be applying different algorithms on a case by case basis to recover this data. The degree to which these algorithms (Head Offsets, Window Shift, ECC, Retries, etc.) must be applied indicates both the stability and the robustness of the design and manufacturing of the physical device.

To remove (or at least control) the use of these algorithms is the purpose of the Diagnostic extensions to SCSI-3.

8.14.1 Physical Geometry

The physical device consists of some number of (typically magnetic recording) disks (platters) which will be used to store information, possibly including, but not limited to, actual user data, sector identification, system operation parameters and actuator positioning data.

For the purposes of disk data (as opposed to positioning data), the smallest addressable entity is called a sector. Sectors are sequentially organized in concentric circles called tracks. The beginning of a track is indicated by a signal (a location) (possibly) called INDEX. The DCS extensions shall generically refer to the track start marker as INDEX. The collection of like tracks on all disk platters is called a cylinder.

The device reads and writes sectors by means of magnetic heads attached to an actuator (linear or rotary). This motor (typically stepper or voice coil) driven actuator is positioned over the correct cylinder and a head (one track) is selected. When the requested sector(s) come under the R/W head the data is passed through the read channel to the controller for processing. Some designs utilize multiple actuator systems.

The SCSI typically views only the User Area of disk cylinders. In actuality, many more cylinders exist for the entire stroke (length the actuator can travel between the stops). The ends of the stroke are typically protected with crash stops to catch runaway actuators. The device may also employ a latch to hold the head-actuator assembly when the media is not spinning. These "other" cylinders can play a large role in system operation as well as be very telling in overall design margin.

By means of the MODE SENSE/MODE SELECT mechanism the user may detect and to some degree control the personality of the physical device. For the purpose of reporting the detailed physical characteristics of the drive geometry, the Cylinder and Track/Sector Map Mode pages are provided.

8.14.2 Motion Control, the Servo System

As stated above, the actuator is controlled via motor to position the head over the correct data track. But often, positioning information exists on the disks to inform the servo system of the current location. It is vital to the longterm usefulness of the Direct Access Device that this positioning information remain intact. Should this information become corrupted, positioning to that specific track may become impossible.

Different types of servo systems include:

- * Open Loop systems: Controlled by only a Stepper Motor with no feed back information during a seek operation.
- * Closed Loop systems: Controlled by either a Stepper Motor or a Voice Coil Motor with positioning information located on a dedicated platter or embedded within the data platters. Different types of embedded servo include sector servo systems, whereby the positioning information is located in fixed locations relative to the sector data and wedge servo systems, whereby the positioning information is located in fixed locations relative to Index (for example) and may cause the fracturing of data fields.

In order to grade a servo system, which is comprised of seeking (moving a single and or multiple cylinder(s)), switching (changing R/W heads without changing cylinders) and settling (declaring ONTRACK after seek completion) algorithms, various seek type tests should be employed. Possible candidates include:

- * Random Seek tests: Stresses the seek (multiple cylinder) portion of the servo system. This typically requires extensive run time to discount the effects of rotational latency.
- * Sequential Seek tests: Stresses the seek (single cylinder) and switch portion of the servo system. This typically requires perfect sector ID field sequencing to discount the effects of Defect Management.
- * Write/Read tests: The above two types of tests should also include be duplicated with Writes and Reads to stress the settling portion of the servo system. Data validity should always be part of the exercise. Note: this test is effected by Read Channel performance and is not strictly a servo issue.

8.14.3 Data Recording and Recovery

The recording and recovering of disk information is typically done via a magnetic head which can induce a magnetic field (write) or detect a magnetic field (read). While the Host System, Initiator and Target Controller view data in terms of bits ('1' or '0'), the Read Channel sees magnetic flux changes. Further, because of the growing need to squeeze more data in smaller area, encoding schemes are employed to get a better than one to one ratio of bits to flux changes. Popular encoding schemes include RLL 1:7 and RLL 2:7. The ability to get at some of the raw Head-Media characteristics is provided by the Diagnostic Erase Track - SEND DIAGNOSTIC and Diagnostic Read Track - SEND DIAGNOSTIC commands.

Both processes, reading and writing, are affected by the Motion Control System's ability to center the head over the requested track.

The Write process is typically a "blind" operation in that the detection of a "bad" write can only be accomplished via a subsequent read of the same location. Further, the ability to accurately place information on the data disks is influenced by the "noise floor" of the location to be written. This noise floor is the composition of many factors, some of which are media defects, read channel quality, system resonances (characteristic frequencies of the system) and PCB interference.

The Read process is likewise affected by the above mentioned items, but is also influenced by the data window. The data window is basically the sliver of time when the Read Channel is expecting to find magnetic information to be interpreted as data. If the Read Channel attempts to read too early or too late, data integrity will be compromised. But, often this window is a moving target if the writing process is also influenced by window shifts (either intentional or otherwise). Controlling window shifts is managed by the use of the R/W Error Recovery Mode (Select) Page.

8.14.4 Data Integrity

The bottom line in any data storage and retrieval device is the ability to accurately maintain data. Because of the decreasing size of such devices, the designing in of "tools" to compensate for less than perfect heads and media and/or positioning systems becomes imperative. Some of these tools that can be controlled by the device as well as the interface include:

- * Data Strobe Offsets (Window Shifts)
- * Head Offsets
- * Error Correction Codes
- * Retries
- * Peak Detection Thresholds

During the certification pass of a Format Unit command, the Direct Access Device may employ several if not all of the above to insure the media can be written and read under all conditions.

8.14.5 The Qualification Process, in General

Typically, a lengthy, thorough investigation is done by the high volume buyer of Rigid Disk Drives. During this time, the device is scrutinized in every possible fashion. The ability to use the above mentioned "tools" permits the assessing of

- * Probability of Errors
- * Thoroughness of design
- * Quality of the Servo System
- * Flexibility of the Read Channel
- * Design Margin of the Product
- * Believability of the Specifications
- * Adequacy of the Defect Management

To speed this process along, the qualifier may perform limited area "formats" with the Diagnostic Write Track - SEND DIAGNOSTIC commands at specific locations on the media (Outer Diameter and Inner Diameter, for example). The Initiator may wish to erase all information from a limited area of the disk and determine the "noise floor" or control Window Shift, Peak detection thresholds and Head offsets to confirm the replacement of those blocks resident in the Plist.

To instruct the qualifier of the general makeup of the device, the Mode Pages for Rigid Disk Drive Geometry, Cylinder Map and Track/Sector Map will lay it all out.

To permit limited area are media formats, the Diagnostic Read Track Interleave - SEND DIAGNOSTIC and Diagnostic Write Track - SEND DIAGNOSTIC commands are provided.

To convert newly assigned physical addresses (Diagnostic Write Track - SEND DIAGNOSTIC) to Logical Block Addresses, SCSI-2 provided the Translate Address Page - SEND DIAGNOSTIC.

To permit the grading of the raw head-media-read channel combination, the Diagnostic Erase Track - SEND DIAGNOSTIC and Diagnostic Read Track - SEND DIAGNOSTIC commands are provided.


To control the device algorithms, Mode parameters to manipulate Head Offsets (R/W Error Recovery), Data Strobe Offsets, also referred to as Window Shift (R/W Error Recovery), Peak Detection Thresholds (R/W Control), Read and Write Retries (R/W Error Recovery) and the use and extent of ECC (R/W Error Recovery) are included.

The following diagram demonstrates the symmetry of the Diagnostic Extensions for SCSI-3:

DIAGNOSTICS EXTENSIONS to SCSI-3

The INVESTIGATIVE Process MODE SENSE/SELECT

Track/Sector Map ———→ Indicates size/length of
Cylinder Map ———→ sector components for the
DWT and DRTI commands.



- DRTI - Diag Read Track Interleave
- DWT - Diagnostic Write Track
- DET - Diagnostic Erase Track
- DRT - Diagnostic Read Track

Diagnostic Extensions to SCSI-3

Cylinder Map MODE page

The Cylinder Map page is provided to indicate the layout of cylinders on the physical drive.

Table 1
 Cylinder Map Mode Page

Bit	7	6	5	4	3	2	1	0
Byte								
0	PS	RSVD	Page Code (0Dh)					
1	Page Length (xxh)						---	
2								
3	CRASH		LATCH		DIRECTION		Reserved	
4	Cylinder Section Descriptor #1						---	
15								
.....								
m	Cylinder Section Descriptor #n						---	
m+11								

where $m = 4 + 12n$, n being the number of Cylinder Section Descriptors.

CRASH: This field is used to indicate the location of the Crash Stop, should one be present.

- 00b: Does not Apply
- 01b: Crash Stop is at the Inner Diameter (ID)
- 10b: Crash Stop is at the Outer Diameter (OD)
- 11b: Crash Stops exist at both Inner and Outer Diameters

LATCH: This field is used to indicate the location of the Latch (location for locked actuator), should one be present.

- 00b: Does not Apply
- 01b: Actuator Latch is at the Inner Diameter (ID)
- 10b: Actuator Latch is at the Outer Diameter (OD)
- 11b: Reserved

DIRECTION: This field is provided to communicate the direction of actuator motion when the Logical Block Address is incremented (discounting Defect Management).

- 00b: Does Not Apply
- 01b: Logical Block Address increases as the actuator travels from OD to ID
- 10b: Logical Block Address decreases as the actuator travels from OD to ID
- 11b: Reserved

Implementor's Note: The above three fields are only reportable during MODE SENSE. Attempts to change these fields in a MODE SELECT shall cause the command to terminate in CHECK CONDITION status. The Sense Key shall be set to ILLEGAL REQUEST, Invalid Field in Parameter List.

Table 2
 Cylinder Section Descriptor

Bit	7	6	5	4	3	2	1	0
Byte								
m	TYPE							
m+1	Reserved							
m+2	(MSB)							
m+3	---							
m+4	Extent Start Cylinder							
m+5	---							
m+5	(LSB)							
m+6	Extent Start Track							
m+7	(MSB)							
m+8	---							
m+9	Extent End Cylinder							
m+10	---							
m+10	(LSB)							
m+11	Extent End Track							

The Cylinder Section Descriptor is provided to describe the purpose of an extent of media tracks as described by TYPE.

TYPE: Section Type Descriptor. This field describes the type of cylinders described for this Cylinder Section Descriptor.

Bit	7	6	5	4	3	2	1	0
	VU	ACCESS			DESCRIPTION			

VU: Vendor Unique. This Cylinder Section type is reserved for Vendor Unique purposes. If this bit is set to 1b, the remainder of the TYPE field is undefined by this document. If this bit is reset to 0b, the ACCESS and DESCRIPTION fields are as described below.

ACCESS: Cylinder Access Availability. This field indicates the allowable method of access the Initiator has to this Cylinder Section.

Table 3a
 Cylinder TYPE Access

<u>ACCESS</u>	<u>Meaning</u>
000b	No Access. These cylinders cannot be accessed by the Initiator under any conditions.
001b	Seek only. The Read/Write heads cannot no be engaged for anything other than positioning purposes while in this Cylinder/Track area. This might only be applicable for dedicated servo type systems.
010b	Read Only. These cylinders can be read by the Initiator, but attempts to write these cylinders will terminate the command in CHECK CONDITION status. The Sense Key shall be set to ILLEGAL REQUEST, Write Protected.
011b	Read/Write. These cylinders' data fields can be modified by the Write process and recovered by the Read process.
100b-111b	Reserved for expansion.

DESCRIPTION: Cylinder Section Description. This field provides general usage information about the specific Cylinder section.

The following table is a breakdown of existing Cylinder Section Descriptions.

Table 3b
 Cylinder TYPE Descriptions

<u>DESCRIPTION</u>	<u>Meaning</u>
0000b	Logical Block Address Space. These cylinders can be addressed as part of the SCSI Logical Block Address space.
0001b	Protection Area. This a safety region of cylinders used to insure drive margins are available.
0010b	Calibration Area. These cylinders are used by the Device to determine optimal operating parameters. Such parameters might include certain compensation factors to overcome mechanical and thermal variances.

- 0011b Diagnostic Area. These cylinders are only used for Diagnostic purposes, such as Power On Self Test and the SEND DIAGNOSTIC command.
- 0100b System Cylinders. These cylinders are used for the general operation of the device. These might include system parameter information, bad block reallocation information, etc.
- 0101b Unused Cylinder Area. These cylinders are part of the entire stroke (Crash stop to Crash stop, for instance), but are not used for any purpose.
- 0111b - 1111b Reserved for expansion.

Extent Start Cylinder: The beginning cylinder number of the Cylinder Section.

Extent Start Track: The beginning track (head) number of the Cylinder Section. This field provides better resolution so that partial cylinder usage can be described. For purposes of consistency, Track Numbers start at 0 and increase monotonically up to the Number of Heads minus 1.

Extent End Cylinder: The ending cylinder number of the Cylinder Section.

Extent End Track: The ending track (head) number of the Cylinder Section. This field provides better resolution so that partial cylinder usage can be described. For purposes of consistency, Track Numbers start at 0 and increase monotonically up to the Number of Heads minus 1.

Implementor's Note #1: All of the above Extent fields (4) are two's complement numbers which monotonically increase with the first User Cylinder being assigned the number 0. This permits negative cylinder notation.

Implementor's Note #2: The Cylinder sections shall be returned in ascending order, with the most negative (or zero, if not applicable) being returned first. Further, cylinder sections are not permitted to overlap each other, although gaps between sections is permissible. These gaps should be interpreted as TYPE 05h (No Access, Unused). Failure to comply with these rules should negate the validity of the Cylinder Map.

Track/Sector Map Mode Page

This Mode Page is used to control/report the repeatable contents from sector pulse to sector pulse as well as those components which are not repeatable within a sector, i.e., track components.

Table 4
 Track/Sector Map Mode Page

Bit	7	6	5	4	3	2	1	0
Byte								
0	PS	RSVD	Page Code (0Eh)					
1	Page Length (4n+1)							
2	(MSB)	Total Physical Sector Length						(LSB)
3								
4	(MSB)	Track/Sector Component Descriptor #1						(LSB)
7								
.....								
4n	(MSB)	Track/Sector Component Descriptor #n						(LSB)
4n+3								

Total Physical Sector Length: This is a count in bytes from a fixed relative point within a sector time to the next same point in the adjacent sector (e.g., sector pulse to sector pulse). This count field should be the sum of the Component Lengths of the subsequent Sector Component Descriptors.

Implementor's Note/WARNING: It is highly probable that the target device can support the changing, i.e., MODE SELECT, of the individual component lengths as long as the sum (Total Physical Sector Length) remains intact. This has highly destructive capacity and should only be used under controlled conditions.

Track/Sector Component Descriptor: The pieces which make up a disk track and/or sector. The ordering of the components shall be as follows:

- (1) All repeatable sector components which are also used in the Diagnostic Read Track Interleave - SEND DIAGNOSTIC command. The ordering of these such components shall be identical to that of the Diagnostic Read Track Interleave - SEND DIAGNOSTIC command.
- (2) All (non-) repeatable sector components which are not part of the Diagnostic Read Track Interleave - SEND DIAGNOSTIC command.
- (3) All track components. Ordering here is not implied.

Table 5
 Track/Sector Component Descriptor

Bit	7	6	5	4	3	2	1	0
Byte								
m	RTI	TRK	DER	Component Type Code				
m+1	Frequency Count							
m+2	(MSB)							
				Component Length				
m+3								(LSB)

RTI: Read Track Interleave component. This bit has meaning only for the MODE SENSE command. If this bit is set to 1b, this field will be returned as part of the Read Track Interleave command. If this bit is reset to 0b, this field will not be included in the Read Track Interleave command. Attempts to alter this bit from its MODE SENSE state for the purposes of MODE SELECT shall cause the MODE SELECT to terminate in CHECK CONDITION status. The Sense Key shall be set to ILLEGAL REQUEST, Invalid Field in Parameter List.

TRK: Track Component. If this bit is set to 1b, the component returned is part of the Track's personality and is not strictly a part of a sector component. If this bit is reset to 0b, the component returned is part of the repeatable portion of a sector.

Implementor's Note: The setting of the both the RTI and TRK bits to 1b is considered an illegal state.

DER: DIAGNOSTIC ERASE/READ. If this bit is set to 1b, the track/sector component will be affected by the Diagnostic Erase Track - SEND DIAGNOSTIC and Diagnostic Read Track - SEND DIAGNOSTIC commands. If this bit is reset to 0b, this component will not be affected by either above the above diagnostic commands.

Component Type Code: This field defines the basic category into which this sector or track component falls:

00h	Post Index
01h	Pre Index
02h	Pre ID
03h	Sector ID (Cylinder Number)
04h	Sector ID (Head Number)
05h	Sector ID (Sector Number)
06h	Sector ID (Flag byte)
07h	Sector ID (CRC)
08h	Sector ID (ECC)
09h	Sector ID (Other)
0Ah	Post ID
0Bh	User Data Field
0Ch	User Data ECC
0Dh	User Data CRC
0Eh	Post Data
0Fh	Absolute Block Address (relative to Disk Start)
10h	ServoBurst
11h -- 1Fh	Reserved
20h -- FFh	Other, Vendor Unique

Frequency Count: This field gives a number of occurrences count for this component on a track in this zone. If this field is not meaningful or is variable in nature, this field will be returned as 00h.

Implementor's Note #1: The intended purpose of this Mode Page is to assist in the usage of the Diagnostic Erase Track - SEND DIAGNOSTIC, Diagnostic Read Track - SEND DIAGNOSTIC and Diagnostic Read Track Interleave - SEND DIAGNOSTIC commands. For the DET and DRT commands, this page gives an approximation of which track fields comprise which bits. Thus, when a Diagnostic Read Track - SEND DIAGNOSTIC indicates a high probability of error exists at bit n, the initiator can determine which track field is most likely affected. For the RTI command, the initiator can be sure of what fields are being controlled.

Implementor's Note #2: To address shifting technologies, the Other, Vendor Unique category should be used in a non-repetitive manner. For example, if the target supports three fields which are not listed in the table above, then three sector component descriptors with codes between 20h and FFh should be used, but they should be unique (e.g., 20h, 21h and 22h).

Implementor's Note #3: There may be a need to incorporate this is the Notch Page to cover that class of device.

Component Length: This field describes the byte length of the track/sector component. If this field does not apply to this component, the Component Length shall be returned as 0000h.

R/W Control Mode Page

Table 6
 MODE Page 0Fh Read-Write Control Page

Bit	7	6	5	4	3	2	1	0
0	Reserved		Page Code (0Fh)					
1	Page Length (0Dh)							
2	TA	TV	Threshold #1					
3	TA	TV	Threshold #2					
4	TA	TV	Threshold #3					
5	TA	TV	Threshold #4					
6	TA	TV	Threshold #5					
7	TA	TV	Threshold #6					
8	TA	TV	Threshold #7					
9	TA	TV	Threshold #8					
10	(MSB)		Reserved					
15							(LSB)	

TA: Threshold Active. This bit indicates whether this is the Peak Threshold currently being used by the Read Channel. If this bit is set to 1b, this threshold was used on the most recent disk access. If this bit is reset to 0b, this threshold was not used on the most recent disk access.

TV: Threshold Valid. This bit indicates whether the Threshold level in bits 5-0 is valid. If this field is set to 1b, bits 5-0 are a valid threshold value supported by the target. If this bit is reset to 0b, bits 5-0 are Reserved and should be set to zero.

Threshold #n: This field indicates a threshold percentage supported by the device. This value has been divided by 2. Thus if a 14h is written into this field, a 40% Peak Threshold Detection is available on this device.

Implementor's Note #1: This MODE Page is meaningful for both MODE SELECT and MODE SENSE. But, if the Initiator should attempt to set the threshold values (in MODE SELECT) to something not supportable, the command shall terminate in CHECK CONDITION status. The Sense Key shall be ILLEGAL REQUEST, Invalid Field in Parameter List.

The suggested use of this page is as follows:

- (1) Issue a MODE SENSE for this page to determine the current and supportable Peak Detection Thresholds.
- (2) Issue a MODE SELECT for this page to change the active threshold. If the selected threshold is not supported (as described by the MODE SENSE) or more than a single TA bit is set to 1b, the target shall terminate the command in CHECK CONDITION status. The Sense Key shall be set to ILLEGAL REQUEST, Invalid Field in Parameter List.

Implementor's Note #2: If the concept of Peak Detection Threshold is not meaningful to the Target, bytes 2 through 9 of the above MODE page should be considered Reserved and set to 00h.

Format Status LOG Page

This LOG page captures the state of the most recent successful FORMAT UNIT and/or Diagnostic Write Track - SEND DIAGNOSTIC command(s) performed.

Table 7
 Format Status LOG Page

Bit	7	6	5	4	3	2	1	0
Byte								
0	Reserved		Page Code (08h)					
1	- Reserved							
2	(MSB)	Page Length (xxxxh)						
3								(LSB)
4	(MSB)	Format Options						
5		Parameter Code (0000h)						(LSB)
6	DU	DS	TSD	ETC	TMC	RSVD	LP	
7		Parameter Length (04h)						
8		Byte 1 of Format Unit CDB						
9		Byte 1 of Defect List Header						
10		Byte 2 of Defect List Header						
11		Byte 3 of Defect List Header						
12	(MSB)	Grown Defects during Certification						
13		Parameter Code (0001h)						(LSB)
14	DU	DS	TSD	ETC	TMC	RSVD	LP	
15		Parameter Length (04h)						
16	(MSB)	Event Count (xxxxxxxxh)						
19								(LSB)
20	(MSB)	Total Blocks Reallocated						
21		Parameter Code (0002h)						(LSB)

(continued next page)

Bit	7	6	5	4	3	2	1	0	
Byte									
22	DU	DS	TSD	ETC	TMC	RSVD	LP		
23	Parameter Length (04h)								
24	(MSB)								
27	Event Count (xxxxxxxh)							(LSB)	
28	(MSB)	Spare Blocks Left Unallocated							
29		Parameter Code (0003h)							(LSB)
30	DU	DS	TSD	ETC	TMC	RSVD	LP		
31	Parameter Length (04h)								
32	(MSB)								
35	Event Count (xxxxxxxh)							(LSB)	
36	(MSB)	Elapsed Time Since Successful Format Unit							
37		Parameter Code (0004h)							(LSB)
38	DU	DS	TSD	ETC	TMC	RSVD	LP		
39	Parameter Length (08h)								
40	(MSB)								
47	Event Count (in minutes)							(LSB)	
48	(MSB)	Diagnostic Write Track Indicator							
49		Parameter Code (0005h)							(LSB)
50	DU	DS	TSD	ETC	TMC	RSVD	LP		
51	Parameter Length (04h * n)								
52	Valid	(MSB)							
53		Diag Write Track Cylinder Number							
54									(LSB)
55	Diag Write Track Number								

Allocation Length: This is a variable count field set to $2Ch + (4n + 4)$ where n is the number of Diagnostic Write Tracks captured in this Log Page. In the above LOG page, bytes 52 through 55 get repeated for each Diagnostic Write Track command performed.

Format Options: This field contains four bytes which capture the set up options employed for the most recent, successful Format Unit operation performed.

Byte 1 of Format Unit CDB: This byte includes the FmtData bit (List passed by Initiator during DATA OUT), CmpLst (List passed by Initiator is complete) and Defect List Format bits.

Byte 1 of Defect List Header: This byte defines the Defect List options.

Bytes 2,3 of Defect List Header: These bytes define the Defect List Length (number of defects in the list).

Grown Defects During Certification Event Counter: This is a counter of the number of defects detected as a result of performing Certification which were not already part of the Plist. If a Certification pass was not performed this field shall be returned as 0000h.

Blocks Reallocated Event Counter: This is a counter of the total blocks reallocated as a result of the FORMAT UNIT operation and any subsequent operation, (includes Grown defects after FORMAT UNIT).

Spares Unallocated Event Counter: This is a counter of the total spare blocks which have yet to be allocated.

Elapsed Operating Time Since Successful FORMAT UNIT Event Count: This field represents the number of usage minutes which have elapsed since the most recently successful FORMAT UNIT command. This field provides for approximately 500 years of counting capability.

Implementor's Note: The fields which are affected by the FORMAT UNIT command should not be updated until its successful completion.

Diagnostic Write Track Indicator: This field exists under the condition a Diagnostic Write Track - SEND DIAGNOSTIC command completes successfully. Note this Event Count may be repeated in the LOG page a number of times. Exhaustion of LOG space is defined within the sections describing LOG SENSE and LOG SELECT. This field is removed from the LOG PAGE upon successful completion of any subsequent FORMAT UNIT command.

Parameter Length: This count divided by four is the number of Tracks which have been affected by the Diagnostic Write Track - SEND DIAGNOSTIC command.

Valid: This bit indicates whether the specific Diagnostic Write Track - SEND DIAGNOSTIC completed successfully. If this bit is set to 1b, the DWT command completed without error. If this bit is reset to 0b, the Track specified in the Diagnostic Write Track Cylinder and Track numbers completed with error. The state of this track is unknown.

Diagnostic Write Track Cylinder Number: This field captures the cylinder number (two's compliment) used in the Diagnostic Write Track - SEND DIAGNOSTIC Page.

Diagnostic Write Track Number: This field captures the track number (two's compliment) used in the Diagnostic Write Track - SEND DIAGNOSTIC Page.

Implementor's Note: Tracks should be reported in ascending order without repetition. Thus, if a specific track is called out in multiple Diagnostic Write Track - SEND DIAGNOSTIC commands, only the most recent command specifics will be retained (whether the DWT command completed successful or not.)

Diagnostic Erase Track - SEND/RECEIVE DIAGNOSTIC

This command is provided for noise measurement and signal distortion detection purposes. This command does not actually imply either DC or AC erase or even the placement of a specific frequency pattern, but must prepare the selected LBA range for relative error probability measurements.

If the Target device supports the Diagnostic Erase Track - SEND DIAGNOSTIC command, then the Diagnostic Read Track - SEND DIAGNOSTIC command must also be supported.

The Diagnostic Erase Track - SEND DIAGNOSTIC command is an INDEX to INDEX write operation where all fields on the specified tracks (minus the exception of the actuator positioning information which may be embedded on the data tracks) are "erased". A successful erase operation leaves the track(s) in a state of a constant frequency pattern. The reading back of this information will yield a pattern representative of the encoding scheme employed by the Read Channel.

Refer to the TRACK/SECTOR Map Mode Page for details about track fields affected by this diagnostic command.

Refer to the Diagnostic Read Track - SEND DIAGNOSTIC command for details on the reading back the erased tracks.

Table 8
 Diagnostic Erase Track - SEND DIAGNOSTIC

Bit	7	6	5	4	3	2	1	0	
Byte									
0	Page Code (41h)								
1	Reserved								
2	(MSB)	Page Length (0008h)							
3								(LSB)	
4	(MSB)	Starting Cylinder							
5									
6								(LSB)	
7		Starting Head							
8	(MSB)	Number of Tracks							
9									
10									
11								(LSB)	

=====

Starting Cylinder: This is the first physical cylinder, using the two's compliment notation (refer to CYLINDER MAP Mode Page for determining cylinder layout) to be affected by this command. If this field is set to a value outside the addressable range of the device, the Target shall terminate the command in CHECK CONDITION status. The Sense Key shall be set to ILLEGAL REQUEST, Invalid Field in Parameter List.

Starting Head: This is the first physical head, (refer to CYLINDER MAP Mode Page for determining cylinder layout) to be affected by this command. If this field is set to a value outside the addressable range of the device, the Target shall terminate the command in CHECK CONDITION status. The Sense Key shall be set to ILLEGAL REQUEST, Invalid Field in Parameter List.

Implementor's Note: Should the Starting Cylinder/Starting Head combination fall into a cylinder section not accessible for this purpose (refer the CYLINDER MAP Mode Page), this command shall terminate in CHECK CONDITION status. the Sense Key shall be set to ILLEGAL REQUEST, Invalid Field in Parameter List.

Number of Tracks: This is the count of tracks that shall be affected by this command. The counting of tracks is dictated by the SURF bit in the FORMAT DEVICE Mode Page. If the Starting Track (determined by the Starting Cylinder/Starting Head combination) plus the Number of Tracks should extent into a cylinder region not accessible for this purpose or should extend outside the physical limits of the device, this command shall be terminated in CHECK CONDITION status. The Sense Key will be set to ILLEGAL REQUEST, Invalid Field in Parameter List.

If the Starting Logical Block plus the Transfer Length should equal a value outside the addressable range of the device, the Target shall terminate the command in CHECK CONDITION status. The Sense Key shall be set to ILLEGAL REQUEST, Invalid Field in Parameter List.

Should the target experience a write error and be unable to "erase" all the tracks requested, the operation will abort on the first failed track.

Table 9
 Diagnostic Erase Track - RECEIVE DIAGNOSTIC

Bit	7	6	5	4	3	2	1	0	
0	Page Code (41h)								
1	Reserved								
2	(MSB)	Page Length (0004h)							
3								(LSB)	
4	(MSB)	Number of Tracks							
5									
6									
7								(LSB)	

Number of Tracks: This is the count of tracks that were successfully "erased". If this count is the same as the Number of Tracks field in the Diagnostic Erase Track - SEND DIAGNOSTIC command, the entire operation can be assumed successful.

Diagnostic Read Track - SEND/RECEIVE DIAGNOSTIC

This command is the counterpart to the Diagnostic Erase Track - SEND DIAGNOSTIC. If this Diagnostic Page is supported it is suggested (but not mandatory) that the Diagnostic Erase Track - SEND DIAGNOSTIC Page also be supported.

The Diagnostic Read Track - SEND DIAGNOSTIC requests the target to return raw track data, i.e., to bypass the decoding process.

Table 10
 Diagnostic Read Track - SEND DIAGNOSTIC

Bit	7	6	5	4	3	2	1	0	
Byte									
0	Page Code (42h)								
1	Reserved								
2	(MSB)	Page Length (0008h)							
3								(LSB)	
4	(MSB)	Starting Cylinder							
5									
6								(LSB)	
7		Starting Head							
8	(MSB)								
9		Number of Tracks							
10									
11								(LSB)	

Starting Cylinder: This is the first physical cylinder, using the two's compliment notation (refer to CYLINDER MAP Mode Page for determining cylinder layout) from which the target shall read. If this field is set to a value outside the addressable range of the device, the Target shall terminate the command in CHECK CONDITION status. The Sense Key shall be set to ILLEGAL REQUEST, Invalid Field in Parameter List.

Starting Head: This is the first physical head, (refer to CYLINDER MAP Mode Page for determining cylinder layout) from which the target shall read. If this field is set to a value outside the addressable range of the device, the Target shall terminate the command in CHECK CONDITION status. The Sense Key shall be set to ILLEGAL REQUEST, Invalid Field in Parameter List.

Implementor's Note: Should the Starting Cylinder/Starting Head combination fall into a cylinder section not accessible for this purpose (refer the CYLINDER MAP Mode Page), this command shall terminate in CHECK CONDITION status. the Sense Key shall be set to ILLEGAL REQUEST, Invalid Field in Parameter List.

Number of Tracks: This is the count of tracks the target shall attempt to read. The counting of tracks is dictated by the SURF bit in the FORMAT DEVICE Mode Page. If the Starting Track (determined by the Starting Cylinder/Starting Head combination) plus the Number of Tracks should extent into a cylinder region not accessible for this purpose or should extend outside the physical limits of the device, this command shall be terminated in CHECK CONDITION status. The Sense Key will be set to ILLEGAL REQUEST, Invalid Field in Parameter List.

If the Starting Logical Block plus the Transfer Length should equal a value outside the addressable range of the device, the Target shall terminate the command in CHECK CONDITION status. The Sense Key shall be set to ILLEGAL REQUEST, Invalid Field in Parameter List.

Should the target experience a read error and be unable to return all the tracks requested, the operation will abort on the first failed track.

Table 11
 Diagnostic Read Track - RECEIVE DIAGNOSTIC

Bit	7	6	5	4	3	2	1	0
Byte								
0	Page Code (42h)							
1	Reserved							
2	(MSB)	Page Length (xxxxh)						(LSB)
3								
4	(MSB)							
5		Number of Tracks						
6								
7								(LSB)
8	(MSB)	First Track Segment						(LSB)
x								
x+1	(MSB)	Second Track Segment						(LSB)
y								
...								
w+1	(MSB)	Last Track Segment						(LSB)
z								

Number of Tracks: This is the count of tracks that were successfully returned. If this count is the same as the Number of Tracks field in the Diagnostic Read Track - SEND DIAGNOSTIC command, the entire operation can be assumed successful.

Track Segment: This is the raw un-decoded track data. The following is a breakdown of a track segment:

Table 12
 Diagnostic Read Track - Track Segment

Bit	7	6	5	4	3	2	1	0
0	Encode Length							
1	Encode Pattern							
x								
x+1	(MSB)							
y	Track Length							
y+1	(LSB)							
z	Track Data							

Encode Length: This field provides the bit count of the encoded pattern in the absence of data. This should be used as the "check" pattern for the rest of the track.

Encode Pattern: This is the actual encode pattern utilized by the Read Channel in the absence of data. The number of bytes used for this field will be the next highest multiple of four above the Encode Length (converted to bytes). The bit pattern in the bytes used to make the Encode Pattern field a multiple of four bytes is not meaningful to this command.

Track Length: This field provides the bit count of the track data being returned for this track.

Track Data: This is the actual track data as seen by the Read Channel. The number of bytes used for this field will be the next highest multiple of four above the Track Length (converted to bytes). The bit pattern in the bytes used to make the Track Data field a multiple of four bytes is not meaningful to this command.

Diagnostic Read Track Interleave - SEND/RECEIVE DIAGNOSTIC

This command is for use in conjunction with the Diagnostic Write Track - SEND DIAGNOSTIC command. This command returns an entire track's worth of Sector IDs in the order they come under the Read/Write heads starting from Index.

Table 13
 Diagnostic Read Track Interleave - SEND DIAGNOSTIC

Bit	7	6	5	4	3	2	1	0
Byte								
0	Page Code (43h)							
1	Reserved							
2	Page Length (06h)							
3								
4	(MSB)	Cylinder						
5								
6								(LSB)
7	Head							
8	(MSB)	Allocation Length						
9								(LSB)

Cylinder: This field defines the Physical Cylinder to which the actuator shall seek prior to reading the Sector IDs. Should this field be set a value outside the limits of the device (as defined by the Rigid Disk Drive Geometry MODE Page), the command shall be terminated in CHECK CONDITION status. The Sense Key shall be set to ILLEGAL REQUEST, Invalid Field in Parameter List.

Head: This field defines the Physical Head to which the device shall switch prior to reading the Sector IDs. Should this field be set a value outside the limits of the device (as defined by the Rigid Disk Drive Geometry MODE Page), the command shall be terminated in CHECK CONDITION status. The Sense Key shall be set to ILLEGAL REQUEST, Invalid Field in Parameter List.

Allocation Length: This field describes the amount of data the Initiator can receive for the Diagnostic Read Track Interleave - RECEIVE DIAGNOSTIC. This field should be set to a minimum of $4+(m*n)$, where m is the Sector ID length as defined in the Track/Sector Map Mode Page and n is the number of Sectors per Track on this device. If this field is set to value less than this, the Target may either terminate the command in CHECK CONDITION status, setting the Sense Key to ILLEGAL REQUEST, Invalid Field in Parameter List, or may simply truncate the returned data in the subsequent Diagnostic Read Track Interleave - RECEIVE DIAGNOSTIC.

Table 14
 Diagnostic Read Track Interleave - RECEIVE DIAGNOSTIC

Bit	7	6	5	4	3	2	1	0
Byte								
0	Page Code (43h)							
1	Reserved							
2	Page Length (xxh)							
3								
4	(MSB)							
5	Cylinder							
6	(LSB)							
7	Head							
8	(MSB)							
8+(m-1)	ID Table Entry #1							
	(LSB)							
.....								
y	(MSB)							
y+(m-1)	ID Table Entry #n							
	(LSB)							

where m is the Sector ID Length and n is the number of Sectors per Track this device supports given the Allocation Length in the corresponding SEND DIAGNOSTIC command was large enough to service all of the return data.

Implementor's Note: Should anything about this command be technically unsupported, the device may reject this diagnostic request. In this case, Page 43h should not be reported via the Supported Pages Diagnostic Page.

Cylinder: This field defines the Physical Cylinder to which the actuator was positioned prior to reading the Sector IDs.

Head: This field defines the Physical Head which was selected prior to reading the Sector IDs.

ID Table Entry: This field describes the contents of the Sector ID components of each sector on the specified track. The specific contents are defined by the returned information in the Track/Sector Map Mode Page.

Diagnostic Write Track - SEND/RECEIVE DIAGNOSTIC

This command permits the Initiator to selectively format (modification of the Sector ID fields) individual tracks on the drive.

Implementor's Note: The suggested use of this command is to precede it with a Diagnostic Read Track Interleave - SEND DIAGNOSTIC and then modify the Sector ID fields as appropriate. This method permits the changing of any number of sectors up to the entire track.

Table 15
 Diagnostic Write Track - SEND DIAGNOSTIC

Bit	7	6	5	4	3	2	1	0	
Byte									
0	Page Code (44h)								
1	Reserved								
2	Page Length (xxh)								
3									
4	(MSB)	Cylinder							
5									
6								(LSB)	
7		Head							
8	(MSB)	ID Table Entry #1							
11								(LSB)	
.....									
m	(MSB)	ID Table Entry #n							
m+3								(LSB)	

where m is the Sector ID Length and n is the number of Sectors per Track this device supports given the Allocation Length in the corresponding SEND DIAGNOSTIC command was large enough to service all of the return data.

The Data fields of the track in question are not controlled by this command. The state of the data after the successful completion of this command is indeterminate.

Implementor's Note: Should anything about this command be technically unsupported, the device may reject this diagnostic request. In this case, Page 44h should not be reported via the Supported Pages Diagnostic Page.

Cylinder: This field defines the Physical Cylinder to which the actuator shall seek prior to the format operation occurring. Should this field be set a value outside the limits of the device (as defined by the Rigid Disk Drive Geometry MODE Page), the command shall be terminated in CHECK CONDITION status. The Sense Key shall be set to ILLEGAL REQUEST, Invalid Field in Parameter List.

Head: This field defines the Physical Head to which the device shall switch prior to the format operation occurring. Should this field be set a value outside the limits of the device (as defined by the Rigid Disk Drive Geometry MODE Page), the command shall be terminated in CHECK CONDITION status. The Sense Key shall be set to ILLEGAL REQUEST, Invalid Field in Parameter List.

ID Table Entry: This field describes the contents of the Sector ID components of each sector on the specified track. The specific contents are defined by the returned information in the Track/Sector Map Mode Page.

Table 16
 Diagnostic Write Track - RECEIVE DIAGNOSTIC

Bit	7	6	5	4	3	2	1	0
0	Page Code (44h)							
1	Reserved							
2	Page Length (02h)							
3								
4	(MSB)	Sector ID Count						
5								(LSB)

Sector ID Count: This field represents the number of successfully written ID fields on the Initiator specified track (in the SEND DIAGNOSTIC counterpart). Should this count field be less than the Sectors per Track for the specified Track, the ID fields of the remaining sectors on the track (absolute sectors beyond the Sector ID Count) are indeterminate.