

ENDL TEXAS

Date: 19 December 2007
 To: T10 Technical Committee
 From: Ralph O. Weber
 Subject: Error history cleanup

Introduction

Several substantive problems were encountered during incorporation of 06-362r7 into SPC-4 r12. This proposal suggests resolutions for these problems.

Revision History

r0 Initial revision

Unless otherwise indicated additions are shown in **blue**, deletions in **red-strikethrough**, and comments in **green**.

Proposed Changes in SPC-4 r12

{{Note: The subclause and table numbers in this revision are from a preliminary SPC-4 r12 draft. When the final SPC-4 r12 is available, r1 of this proposal will be posted with the correct numbers.}}

3.1 Definitions

3.1.h Error history I_T nexus: An I_T nexus for which the device server has reserved access to the error history snapshot (see 3.1.i).

3.1.i Error history snapshot: The contents of the error history at a specific point in time. See 5.11.2.

...

5.11.2 Retrieving error history with the READ BUFFER command

...

To retrieve the complete error history, an application client uses one I_T nexus to:

- 1) Create an error history snapshot if one does not already exist, establish the I_T nexus as the error history I_T nexus, and retrieve the error history directory by sending a READ BUFFER command (see 6.16.9.2) with:
 - A) The MODE field set to 1Ch (i.e., error history);
 - B) The BUFFER ID field set to one of the following:
 - a) If the error history I_T nexus is expected to be valid:
 - A) 00h (i.e., return error history directory);
 - B) 01h (i.e., return error history directory and create new snapshot);
 - b) If the application client has knowledge obtained by means outside the scope of this standard that the error history I_T nexus is no longer valid:
 - A) 02h (i.e., return error history directory and establish new error history I_T nexus); or

- B) 03h (i.e., return error history directory, establish new error history I_T nexus, and create new snapshot);
 - C) The BUFFER OFFSET field set to 000000h; and
 - D) The ALLOCATION LENGTH field set to at least 2 088 (i.e., large enough to transfer the complete error history directory);
- 2) Retrieve the error history. The application client uses a data-in buffer size that is a multiple of the offset boundary indicated in the READ BUFFER descriptor (see 6.16.5). For each buffer ID indicated in the error history directory in the range of 10h through EFh, the application client sends one or more READ BUFFER commands (see 6.16.9.3) as follows: with:
- ~~A) The MODE field set to 1Ch (i.e., return error history);~~
 - ~~B) The BUFFER ID field set to the buffer ID (i.e., an error history data buffer); and~~
 - ~~C) The ALLOCATION LENGTH field set to the size of the data-in buffer.~~
- ~~For the first READ BUFFER command for a particular buffer ID, the application client sets the BUFFER OFFSET field to 000000h. If the number of bytes returned does not equal the allocation length and the total number of bytes returned from the buffer ID does not equal the maximum available length indicated in the error history directory, there is more data in the buffer ID and the application client sends another READ BUFFER command with:~~
- ~~A) The MODE field set to 1Ch (i.e., error history);~~
 - ~~B) The BUFFER ID field set to the buffer ID (i.e., an error history data buffer);~~
 - ~~C) The BUFFER OFFSET field set to the previous buffer offset plus the previous allocation length; and~~
 - ~~D) The ALLOCATION LENGTH field set to the size of the data-in buffer;~~
- 1) Send the first READ BUFFER command with:
 - a) The MODE field set to 1Ch (i.e., error history);
 - b) The BUFFER ID field set to the buffer ID (i.e., an error history data buffer);
 - c) The BUFFER OFFSET field set to 000000h; and
 - d) The ALLOCATION LENGTH field set to the size of the data-in buffer;
 - 2) Send zero or more additional READ BUFFER commands with:
 - a) The MODE field set to 1Ch (i.e., error history);
 - b) The BUFFER ID field set to the buffer ID (i.e., an error history data buffer);
 - c) The BUFFER OFFSET field set to the previous buffer offset plus the previous allocation length; and
 - d) The ALLOCATION LENGTH field set to the size of the data-in buffer;
- and
- 3) Clear the error history I_T nexus and, depending on the buffer ID, release the error history snapshot by sending a READ BUFFER command with:
- A) The MODE field set to 1Ch (i.e., error history); and
 - B) The BUFFER ID field set to:
 - a) FEh (i.e., clear error history I_T nexus) (see 6.16.9.4); or
 - b) FFh (i.e., clear error history I_T nexus and release snapshot) (see 6.16.9.5);
 - ~~C) The BUFFER OFFSET field set to 000000h; and {{Conflicts with table 148.}}~~
 - ~~D) The ALLOCATION LENGTH field set to 000000h. {{Conflicts with wording in 6.16.9.4 and 6.16.9.5.}}~~

While an error history snapshot exists, the device server:

- a) Shall not modify the error history snapshot to reflect any changes to the error history;
- b) May or may not record events that it detects into the error history; and
- c) If it supports the WRITE BUFFER command download application client error history mode (see 6.38.14), shall record any application client error history received into the error history.

The device server shall clear the established error history I_T nexus and not release the error history snapshot when:

- a) Upon processing of a READ BUFFER command on the error history I_T nexus with:
 - A) The MODE field set to 1Ch (i.e., error history); and
 - B) The BUFFER ID field set to FEh (i.e., clear error history I_T nexus) (see 6.16.9.4);

- ~~C) The BUFFER OFFSET field set to 000000h; and {{Conflicts with table 148.}}~~
 - ~~D) The ALLOCATION LENGTH field set to 000000h; {{Conflicts with wording in 6.16.9.4.}}~~
- or

- b) An I_T nexus loss occurs on the error history I_T nexus.

The device server shall clear the established error history I_T nexus and release the error history snapshot when:

- a) Upon processing of a READ BUFFER command using the same I_T nexus that was used to establish the snapshot with:
 - A) The MODE field set to 1Ch (i.e., error history);
 - B) The BUFFER ID field set to FFh (i.e., clear error history I_T nexus and release snapshot) (see 6.16.9.5);
 - ~~C) The BUFFER OFFSET field set to 000000h; and {{Conflicts with table 148.}}~~
 - ~~D) The ALLOCATION LENGTH field set to 000000h; {{Conflicts with wording in 6.16.9.5.}}~~
- b) A power on occurs;
- c) A hard reset occurs; or
- d) A logical unit reset occurs.

The device server shall not replace or release the error history snapshot while the error history I_T nexus is established.

...

5.11.4 Clearing error history with the WRITE BUFFER command

An application client clears the portions of the error history that the device server allows to be cleared by sending a WRITE BUFFER command (see 6.38.14) with:

- a) The MODE field set to 1Ch (i.e., download error history);
- ~~b) The BUFFER OFFSET field set to 000000h; {{Conflicts with 6.38.14.}}~~
- c) The PARAMETER LIST LENGTH field set to at least 00001Ah; and
- d) In the parameter list, the CLR bit set to one; and
- ~~e) All other fields in the parameter list each set to zero. {{Conflicts with 6.38.14.}}~~

Clearing error history shall not affect the contents of the error history snapshot, if any, and/or error history I_T nexus, if any, that ~~has~~ have been created with the READ BUFFER command (see 5.11.2).

6.16.9.1 Error history overview

... {{The following deleted text is covered by change in table 148 and the new paragraph that follows it.}}

~~The device server shall terminate the command with CHECK CONDITION status with the sense key set to ILLEGAL REQUEST and the additional sense code set to OPERATION IN PROGRESS if the following condition is detected:~~

- ~~a) an error history snapshot exists;~~
- ~~b) an error history I_T nexus exists (i.e., the device server has reserved access to the error history snapshot for a particular I_T nexus); and~~
- ~~c) the device server receives a READ BUFFER command with the MODE field set to 1Ch and the BUFFER ID field set to a value other than 02h or 03h from an I_T nexus different than the error history I_T nexus.~~

The BUFFER ID field (see table 148) specifies the action that the device server shall perform, and the parameter data, if any, that the device server shall return.

Table 148 — Error history BUFFER ID field

Code	Description	Buffer offset	Error history I_T nexus constrained	Reference
00h	Return error history directory	0000h	Yes	6.16.9.2
01h	Return error history directory and create new error history snapshot (see 3.1.i)	0000h	Yes	6.16.9.2
02h	Return error history directory and establish new error history I_T nexus (see 3.1.h)	0000h	No	6.16.9.2
03h	Return error history directory, establish new error history I_T nexus, and create new error history snapshot	0000h	No	6.16.9.2
04h - 0Fh	Reserved			
10h - EFh	Return error history	0000h - FFFFh	Yes	6.16.9.3
F0h - FDh	Reserved			
FEh	Clear error history I_T nexus	Ignored	Yes	6.16.9.4
FFh	Clear error history I_T nexus and release error history snapshot	Ignored	Yes	6.16.9.5

If the device server receives a READ BUFFER command with the MODE field set to 1Ch with the BUFFER ID field is set to a value that table 148 shows as constrained by error history I_T nexus from an I_T nexus that is different than the established error history I_T nexus, if any, while an error history snapshot exists, then the command shall be terminated with CHECK CONDITION status with the sense key set to ILLEGAL REQUEST and the additional sense code set to OPERATION IN PROGRESS.

...

6.16.9.2 Error history directory

If:

- a) there is no error history I_T nexus;
- b) the BUFFER ID field is set to 00h or 01h and the I_T nexus performing the READ BUFFER command is the error history I_T nexus; or
- c) the BUFFER ID field is set to 02h or 03h,

then the device server shall:

- a) if an error history snapshot does not already exist, create an error history snapshot of the error history;
- b) if an error history snapshot already exists and the BUFFER ID field is set to 00h or 02h, preserve the error history snapshot;
- c) if an error history snapshot already exists and the BUFFER ID field is set to 01h or 03h, discard the error history snapshot and create another error history snapshot of the error history;
- d) set the error history I_T nexus to the I_T nexus being used for the READ BUFFER command; and
- e) return an error history directory (see table 149) indicating the error history that is available for retrieval and is stored in the error history snapshot.

Unless constrained by an established error history I_T nexus (see 6.16.9.1), all error history device server actions return an error history directory (see table 149). Some error history device server actions also discard the existing error history snapshot (see 3.1.i) and create a new error history snapshot (see table x1).

Table x1 — Summary of error history directory device server actions

BUFFER ID field	Establish new error history I_T nexus (see 3.1.h)	Error history snapshot (see 3.1.i)	
		Preserved (if exists)	Created
00h	No ^a	Yes	No ^b
01h	No ^a	No	Yes
02h	Yes	Yes	No ^b
03h	Yes	No	Yes

^a If no error history I_T nexus is established, a new one is established.
^b If no error history snapshot exists, a new one is created.

If an error history snapshot already exists, the device server shall not consider this an error.

{{CAP Check: Is the above statement really needed? It seems obvious from the contents of table x1.}}

The error history directory is defined in table 149.

Table 149 — Error history directory {{no changes in this table}}

...

6.16.9.3 Error history data buffer

~~The~~ Unless an error is encountered, the device server shall return parameter data that contains error history in a vendor specific format from the error history snapshot from the specified buffer at the specified buffer offset. ~~if all of the following are true:~~

- ~~a) the I_T nexus performing the READ BUFFER command is the error history I_T nexus;~~
- ~~b) the BUFFER ID field is set to a value in the range of 10h to EFh that is indicated as supported in the error history directory (see 6.16.9.2); and~~
- ~~c) the BUFFER OFFSET field is set to a valid value.~~

If the device server receives a READ BUFFER command with the MODE field set to 1Ch from the established error history I_T nexus and the BUFFER ID field is set to a value that the error history directory (see 6.16.9.2) shows as not supported, then the command shall be terminated with CHECK CONDITION status with the sense key set to ILLEGAL REQUEST and the additional sense code set to INVALID FIELD IN CDB.

If the value in the BUFFER OFFSET field is not supported, the command shall be terminated with CHECK CONDITION status with the sense key set to ILLEGAL REQUEST and the additional sense code set to INVALID FIELD IN CDB.

The amount of error history in the specified buffer shall be less than or equal to the number of bytes indicated by the MAXIMUM AVAILABLE LENGTH field in the error history directory (see 6.16.9.2).

6.16.9.4 Clear error history I_T nexus

~~{{Deletions in this subclause are covered by the changes in 6.16.9.1.}}~~

If the BUFFER ID field is set to FEh ~~and the READ BUFFER command is received on the error history I_T nexus,~~ ~~then~~ the device server shall:

- a) Clear the error history I_T nexus, if any; and
- b) Not transfer any data.

~~If no error history I_T nexus is established, the device server shall not consider this an error.~~

6.16.9.5 Clear error history I_T nexus and release snapshot

~~{{Deletions in this subclause are covered by the changes in 6.16.9.1.}}~~

If the BUFFER ID field is set to FFh ~~and the READ BUFFER command is received on the error history I_T nexus,~~ ~~then~~ the device server shall:

- a) Clear the error history I_T nexus, if any,
- b) Release the error history snapshot, if any; and
- c) Not transfer any data.

~~If no error history I_T nexus is established, the device server shall not consider this an error.~~

...

6.38.14 Download application client error history mode (1Ch)

...

A If the CLR_SUP bit is set to one in the error history directory parameter data (see 6.16.9.2), a CLR bit set to one specifies that the device server shall:

- a) Clear the portions of the error history that the device server allows to be cleared; and
- b) ~~Clear the error history I_T nexus, if any; {{Conflicts with 5.11.4.}}~~
- c) ~~Release the error history snapshot, if any; and {{Conflicts with 5.11.4.}}~~
- d) Ignore any application client error history specified in the parameter list.

~~A CLR bit set to zero specifies that the device server shall not ignore the CLR bit.~~

If the CLR_SUP bit is set to one in the error history directory parameter data, a CLR bit set to zero specifies that the device server shall:

- a) Not clear the error history, error history I_T nexus, or release the error history snapshot;
- b) Process all application client error history specified in the parameter list.

If the CLR_SUP bit is set to one in the error history directory parameter data, the device server shall ignore the CLR bit.