

**T10/00-147r0**

# **Ultra320 SCSI vs Ultra160 SCSI Eye Diagram Data**

**Russ Brown  
Quantum Corporation**


**SCSI Physical Working Group Meeting  
09 Feb 2000  
Huntington Beach, CA**

- Evaluate Ultra160 margins with the same techniques as used for our Ultra320 data
  - Ultra160 transmitter drive level used for evaluation was 400mV peak-to-peak differential
  - Ultra320 data was taken from presentation (00-104r0)
    - 400mV peak-to-peak differential for No Comp and Rx Equalized
    - 400mV / 720mV peak-to-peak differential for Tx Precomp
- Measure the signal degradations to find eye opening with ISI, reflections and crosstalk for typical configurations, including:
  - Amplitude errors;
  - Timing shift errors;
  - Miscellaneous noise.


			U-320	U-160
Random amplitude (0-to-pk)	Terminator voltage mismatch	(SPI-3: Tab20)	13mV	13mV
	Terminator resistance mismatch	(SPI-3: Tab20)	5mV	5mV
	Driver error	(SPI-3: TabA2)	40mV	40mV
	Receiver comparator	(SPI-3: TabA5)	30mV	30mV
	Root sum squares of random amplitude		52mV	52mV
Deterministic Amplitude: (0-to-pk)	Cable + back-plane resistance (cable spec + meas)		28mV	28mV
	Comparator overdrive requirement (SPI-3: Fig48)		70mV	70mV
	Total amplitude 0-to-pk factors:		150mV	150mV
Timing factors (0-to-pk)	Low Vt vs substrate noise	(99-261r1)	100ps	50ps
	Receiver clock jitter	(99-261r1)	125ps	250ps
	Residual de-skew	(99-261r1)	125ps	3.3ns
	De-skew stability (temperature)		100ps	N/A
	Input slew rate dependent skew	(99-261r1)	100ps	100ps
	Receiver amp dependent delay (99-261r1*)		150ps	150ps
	Receiver FF rise/fall prop delay difference		300ps	300ps
	Total 0-to-pk timing factors:		1.0ns	4.15ns

These are the error sources that are not accounted for by our test setup as well as those in the SPI-3 budget. 0-to-peak values converted from peak-to-peak numbers by a factor of 1/2.

- Error sources are used to define the range over which a receiver characteristic may typically vary from the ideal sample point, i.e., the actual sample point may lie anywhere within a box defined by 2 times 0-to-peak height and 2 times 0-to-peak width of the errors.




U320 Eye Mask



U160 Eye Mask  
notched as in Fig 48, SPI-3

- Amplitude error sources define height, and timing error sources define width, e.g., set-up time margin is measured as the distance from the eye diagram waveform to the box.


- 10 meter Madison 28AWG<sup>†</sup> round shielded cable plus 6-slot backplane.
- Waveforms captured @ 4Gs/s:
  - no pre-comp:  $\Delta A = 0.0$  (refer to 99-335r0)
  - amplitude pre-comp:  $\Delta A = 0.8$



<sup>†</sup> Supplied by Amphenol

# Quantum™ Config 2: Short Cable + Backplane


- 2.25 meter Hitachi 32AWG twisted-flat cable<sup>†</sup> plus 6-slot backplane.
- Waveforms captured @ 4Gs/s:
  - no pre-comp:  $\Delta A = 0.0$  (refer to 99-335R0)
  - amplitude pre-comp:  $\Delta A = 0.8$





<sup>†</sup>supplied by Hitachi & Circuit Assembly

# Quantum™ Config 3: Loaded Long Cable + BP

- Hitachi 10 meter 32AWG twisted-flat ribbon cable<sup>†</sup> with 25cm load spacing plus 6-slot backplane.
- Waveforms captured @ 4Gs/s:
  - no pre-comp:  $\Delta A = 0.0$  (refer to 99-335R0)
  - amplitude pre-comp:  $\Delta A = 0.8$









**Conclusion: Failing Margin**


(Increasing amplitude would still fail)



**Conclusion: Failing Margin**  
(Can't increase amplitude to improve margin)




Conclusion: Excellent Margin




**Conclusion: Failing Margin\***


(\*Increasing amplitude would make margin adequate)



Conclusion: Adequate Margin




Conclusion: Adequate Margin




Conclusion: Excellent Margin


\*2.25m twisted-flat cable + loaded 6-slot backplane @ bp1



**Conclusion: Excellent Margin**




Conclusion: Failing Margin



**Conclusion: Insufficient Margin**


(Can't increase amplitude to improve margin)



**Conclusion: Excellent Set-up Margin\***

(\*Increased amplitude would make Hold margin adequate)

\*10m twisted-flat cable w/9 loads + loaded 6-slot backplane @ cp9



**Conclusion: Failing Margin\***

(\*Increasing amplitude would make margin adequate))

<b>Configuration</b> (description)	<b>Ultra320</b>			<b>Ultra160</b>
	<b>No Comp</b>	<b>w/Tx Pre-comp</b>	<b>w/Rx Equalizer</b>	
1 (10m round cable + loaded 6-slot backplane @ bp1)	Failing margin	Failing margin	Excellent margin	Failing margin *
2 (2.25m flat cable + loaded 6-slot backplane @ bp1)	Adequate margin	Adequate margin	Excellent margin	Excellent margin
3 (10m twisted-flat cable w/9 loads + loaded 6-slot backplane @ cp9)	Failing margin	Insufficient margin	Excellent Set-up margin	Failing margin *

\* Increasing amplitude would make margin adequate.

- ① U160 eye diagrams show adequate margin with all configurations (though getting close with 10m cable with 16 loads)
- ② U320 provides adequate margin without precomp or equalization with a short cable (2.5m) configuration
- ③ U320 using transmitter precomp provides insufficient margin with typical configurations
- ④ U320 using receiver equalization provides excellent margins with all configurations